

**Fuel Pressure Gauge 002**

(Glycerine filled)  
0 -7bar (0-100Psi)  
1/8 NPTF



*Fuel gauge is for setting up pressure only. Not for permanent fitment*